

## Introduction

This service manual describes the service procedures for the MAGNA VF750C/CD.

This Model Specific Manual includes every service procedure that is of a specific nature to this particular model. Basic service procedures that are common to other Honda Motorcycle/Motor Scooter/ATVs are covered in the Common Service Manual. This Model Specific Service Manual should be used together with the Common Service Manual in order to provide complete service information on all aspects of this motorcycle.

Follow the Maintenance Schedule (Section 3) recommendations to ensure that the vehicle is in peak operating condition and the emission levels are within the standards set by the U.S. Environmental Protection Agency and the California Air Resources Board. Performing the first scheduled maintenance is very important. It compensates for the initial wear that occurs during the break-in period.

Sections 1 and 3 apply to the whole motorcycle. Section 2 illustrates procedures for removal/installation of components that may be required to perform service described in the following sections. Sections 4 through 19 describe parts of the motorcycle, grouped according to location.

Find the section you want on this page, then turn to the table of contents on the first page of the section.

Most sections describe the service procedure through system illustration. Refer to the next page for details on how to use this manual.

If you are not familiar with this motorcycle, read Technical Feature in section 20.

If you don't know the source of the trouble, go to section 21 Troubleshooting.

All information, illustrations, directions and specifications included in this publication are based on the latest product information available at the time of approval for printing. Honda Motor Co., LTD. reserves the right to make changes at any time without notice and without incurring any obligation whatever. No part of this publication may be reproduced without written permission. This manual is written for persons who have acquired basic knowledge of maintenance on Honda motorcycles, motor scooters or ATVs.

HONDA MOTOR CO., LTD.  
Service Publications Office


## Contents

	General Information	1
	Frame/Body Panels/Exhaust System	2
	Maintenance	3
Engine and Drive Train	Lubrication System	4
	Fuel System	5
	Cooling System	6
	Engine Removal/Installation	7
	Cylinder Head/Valves	8
	Clutch System	9
	Gearshift Linkage	10
	Crankshaft/Piston/Transmission	11
Chassis	Front Wheel/Suspension/Steering	12
	Rear Wheel/Suspension	13
	Brake System	14
Electrical	Charging System/Alternator	15
	Ignition System	16
	Electric Starter/Starter Clutch	17
	Lights/Meters/Switches	18
	Wiring Diagram	19
	Technical Feature	20
	Troubleshooting	21
	Index	22

# How To Use This Manual

## Finding The Information You Need

- This manual is divided into sections which cover each of the major components of the motorcycle.
- To quickly find the section you are interested in, the first page of each section is marked with a black tab that lines up with one of the thumb index tabs before this page.
- The first page of each section lists the table of contents within the section.
- Read the service information and troubleshooting related to the section before you begin working.
- An index of the entire book is provided in the last chapter to directly locate the information you need.



## Note On the Explanation Method Of This Manual

- The removal and installation of parts are for the most part illustrated by large and clear illustrations that should provide the reader with visual aid in understanding the major point for servicing.
- The system illustrations are augmented by call outs whose numbers or letters indicate the order in which the parts should be removed or installed.
- The sequence of steps represented numerically are differentiated from the ones represented alphabetically to notify the reader that they must perform these steps separately.
- The illustrations may contain symbols to indicate necessary service procedures and precautions that need to be taken. Refer to the next page for the meaning of each symbol.
- Also in the illustration is a chart that lists information such as the order in which the parts are removed/installed, the name of the part, and some extra notes that may be needed.
- Step by step instructions are provided to supplement the illustrations when detailed explanation of the procedure is necessary or illustrations alone would not suffice.
- Service procedures required before or after the procedure described on that particular page, or inspection/adjustment procedures required following the installation of parts, are described under the title Requisite Service.
- Standard workshop procedures and knowledge covered in the Common Service Manual are abbreviated in this manual.

**System illustration**

**Symbols**

**Detailed description of the procedure**

**Step sequence (numerals or alphabets)**

**Part name**

**Number of parts**

**Extra notes or precaution related to the service procedure**

**Rear Wheel/Suspension**

**Swingarm Disassembly/Assembly**

**Requisite Service**

Procedure	Qty	Remarks
(11) Shimlocknut (Order)	1	Assembly is in the reverse order of disassembly.
(12) Shimlocknut (Order)	1	
(13) Drive sprocket guard plate	1	Reassembly (page 12-14)
(14) Right panel roller	1	
(15) Clutch line	1	Reassembly (page 12-15)
(16) Right handle bearing	1	
(17) Left panel roller	1	Reassembly (page 12-14)
(18) Clutch ring	1	
(19) Ball bearing	1	Reassembly (page 12-15)
(20) Left handle bearing	1	

12-14

**Independent Front Bearing Replacement**

Press the left needle bearings out of the swingarm joint.

Remove bearing driver **8796-KA2000**

Remove the snap ring.

Press the right needle bearings out of the swingarm joint.

Remove bearing driver **8796-KA2000**

Confirmly press the ball bearings into the swingarm ball joint.

NOTE: Install the bearing with the marks facing out.

Drive **8796-KA1000**  
Adjustment, 32 x 50mm **8796-KA1100**  
File, 15mm **8796-KA1000**

Confirmly press the needle bearings into the swingarm joint.

NOTE: Install the bearing with the marks facing out.

Remove bearing driver **8796-KA2000**

**10 BEARING REMOVER**

**11 SPIDER SHAFT**

**12 ATTACHMENT** 12 mm Ø 13 H7















**13 BEARING DRIVER**

12 mm Ø 13 H7  
12 mm Ø 13 H7  
12 mm Ø 13 H7

12-15

# Symbols

The symbols used throughout this manual show specific service procedures. If supplementary information is required pertaining to these symbols, it would be explained specifically in the text without the use of the symbols.

	<p>Replace the part(s) with new one(s) before assembly.</p>
	<p>Use special tool.</p>
	<p>Use optional tool. These tools are obtained as you order parts.</p>
 10 (1.0,7)	<p>Torque specification. 10 N·m (1.0 kg-m, 7 ft-lb)</p>
	<p>Use recommended engine oil, unless otherwise specified.</p>
	<p>Use molybdenum oil solution (mixture of the engine oil and molybdenum grease with the ratio 1:1).</p>
	<p>Use multi-purpose grease (Lithium based multi-purpose grease NLGI #2 or equivalent).</p>
	<p>Use molybdenum disulfide grease (containing more than 3% molybdenum disulfide, NLGI #2 or equivalent).            Example: Molykote® BR-2 plus manufactured by Dow Corning, U.S.A.            Multi-purpose M-2 manufactured by Mitsubishi Oil Japan</p>
	<p>Use molybdenum disulfide paste (containing more than 40% molybdenum disulfide, NLGI #2 or equivalent).            Example: Molykote® G-n Paste manufactured by Dow Corning, U.S.A.            Honda Moly 60 (U.S.A. only)            Rocol ASP manufactured by Rocol Limited, U.K.            Rocol Paste manufactured by Sumico Lubricant, Japan</p>
	<p>Use silicone grease.</p>
	<p>Apply a locking agent. Use the agent of the middle strength, unless otherwise specified.</p>
	<p>Apply sealant.</p>
	<p>Use brake fluid DOT 4. Use the recommended brake fluid, unless otherwise specified.</p>
	<p>Use Fork or Suspension Fluid.</p>

# 1. General Information

1

General Safety	1-1	Lubrication & Seal Points	1-17
Model Identification	1-3	Cable & Harness Routing	1-20
Specifications	1-4	Emission Control System (U.S.A. Only)	1-27
Torque Values	1-12	Emission Control Information Labels (U.S.A Only)	1-30
Tools	1-15		

## General Safety

### Carbon Monoxide

If the engine must be running to do some work, make sure the area is well ventilated. Never run the engine in an enclosed area.

#### ⚠ WARNING

- The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and may lead to death.

Run the engine in an open area or with an exhaust evacuation system in an enclosed area.

### Gasoline

Work in a well ventilated area. Keep cigarettes, flames or sparks away from the work area or where gasoline is stored.

#### ⚠ WARNING

- Gasoline is extremely flammable and is explosive under certain conditions. KEEP OUT OF REACH OF CHILDREN.

### Hot Components

#### ⚠ WARNING

- Engine and exhaust system parts become very hot and remain hot for some time after the engine is run. Wear insulated gloves or wait until the engine and exhaust system have cooled before handling these parts.

### Used Engine/Transmission Oil

#### ⚠ WARNING

- Used engine oil (or transmission oil in two-stroke) may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil. KEEP OUT OF REACH OF CHILDREN.

### Brake Dust

Never use an air hose or dry brush to clean brake assemblies. Use an OSHA-approved vacuum cleaner or alternate method approved by OSHA, designed to minimize the hazard caused by airborne asbestos fibers.

#### ⚠ WARNING

- Inhaled asbestos fibers have been found to cause respiratory disease and cancer.

### Brake Fluid

#### CAUTION

- Spilling fluid on painted, plastic or rubber parts will damage them. Place a clean shop towel over these parts whenever the system is serviced. KEEP OUT OF REACH OF CHILDREN.

## General Information

---

### Coolant

Under some conditions, the ethylene glycol in engine coolant is combustible and its flame is not visible. If the ethylene glycol does ignite, you will not see any flame, but you can be burned.

#### ⚠ WARNING

- Avoid spilling engine coolant on the exhaust system or engine parts. They may be hot enough to cause the coolant to ignite and burn without a visible flame.
- Coolant (ethylene glycol) can cause some skin irritation and is poisonous if swallowed. **KEEP OUT OF REACH OF CHILDREN.**
- Do not remove the radiator cap when the engine is hot. The coolant is under pressure and could scald you.
- Keep hands and clothing away from the cooling fan, as it starts automatically.

If it contacts your skin, wash the affected areas immediately with soap and water. If it contacts your eyes, flush them thoroughly with fresh water and get immediate medical attention. If it is swallowed, the victim must be forced to vomit, then rinse mouth and throat with fresh water before obtaining medical attention. Because of these dangers, always store coolant in a safe place, away from the reach of children.

### Nitrogen Pressure

For shock absorbers with a gas-filled reservoir:

#### ⚠ WARNING

- Use only nitrogen to pressurize the shock absorber. The use of an unstable gas can cause a fire or explosion resulting in serious injury.
- The shock absorber contains nitrogen under high pressure. Allowing fire or heat near the shock absorber could lead to an explosion that could result in serious injury.
- Failure to release the pressure from a shock absorber before disposing of it may lead to a possible explosion and serious injury if it is heated or pierced.

To prevent the possibility of an explosion, release the nitrogen by pressing the valve core. Then remove the valve stem from the shock absorber reservoir. Dispose of the oil in a manner acceptable to the Environmental Protection Agency (EPA).

Before disposal of the shock absorber, release the nitrogen by pressing the valve core. Then remove the valve stem from the shock absorber.



### Battery Hydrogen Gas & Electrolyte

#### ⚠ WARNING


- The battery gives off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging.
- The battery contains sulfuric acid (electrolyte). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.
  - If electrolyte gets on your skin, flush with water.
  - If electrolyte gets in your eyes, flush with water for at least 15 minutes and call a physician immediately.
- Electrolyte is poisonous.
  - If swallowed, drink large quantities of water or milk and follow with milk of magnesia or vegetable oil and call a physician. **KEEP OUT OF REACH OF CHILDREN.**

## Model Identification


'94 MAGNA VF750C shown




(1) The frame serial number is stamped on the right side of the steering head.




(2) The engine serial number is stamped on the right side of the upper crankcase.



(3) The vehicle Identification Number (VIN) is located on the Safety Certification Label on the left side of the steering head.



(4) The carburetor identification number is stamped on the carburetor body intake side.



(5) The color label is attached as shown. When ordering color-coded parts, always specify the designated color code.

# Specifications

General			
	Item		Specifications
Dimensions	Overall length	'94-'00	2,332 mm (91.8 in)
		After '00	2,338 mm (92.0 in)
	Overall width		854 mm (33.6 in)
	Overall height	(VF750C)	1,136 mm (44.7 in)
		(VF750CD)	1,190 mm (46.9 in)
	Wheelbase		1,652 mm (65 in)
	Seat height		710 mm (28 in)
	Footpeg height		290 mm (11.4 in)
	Group clearance		155 mm (6.1 in)
	Dry weight		
		(VF750C: 49 states, Canadian type)	229 kg (505 lbs)
		(VF750C: California type)	231 kg (509 lbs)
		(VF750CD: 49 states, Canadian type)	230 kg (507 lbs)
		(VF750CD: California type)	232 kg (511 lbs)
	Curb weight		
	(VF750C: 49 states, Canadian type)	247 kg (545 lbs)	
	(VF750C: California type)	249 kg (549 lbs)	
	(VF750CD: 49 states, Canadian type)	248 kg (547 lbs)	
	(VF750CD: California type)	250 kg (551 lbs)	
	Maximum weight capacity		180 kg (397 lbs)
Frame	Frame type		Double cradle
	Front suspension		Telescopic fork
	Front wheel travel		150 mm (5.91 in)
	Rear suspension		Swingarm
	Rear wheel travel		100 mm (3.94 in)
	Rear damper		Double effect type
	Front tire size		120/80 - 17 61V
	Rear tire size		150/80 - 15M/C 70V
	Tire brand (Front/Rear)		K555F/K555 (Dunlop)
	Front brake		Hydraulic brake
	Rear brake		Internal expanding shoe
	Caster angle		32°
	Trail length		137 mm (5.39 in)
	Fuel tank capacity		13.9 liter (3.7 US gal, 3.1 Imp gal)
Fuel tank reserve capacity		3.3 liter (0.87 US gal, 0.37 Imp gal)	
Engine	Bore and stroke		70.0 x 48.6 mm (2.76 x 1.91 in)
	Displacement		748.1 cc (45.65 cu-in)
	Compression ratio		10.8 : 1
	Valve train		Silent multi-link chain drive and DOHC
	Intake valve opens (at 1 mm lift)		10° BTDC
	Intake valve closes (at 1 mm lift)		25° ABDC
	Exhaust valve opens (at 1 mm lift)		35° BBDC
	Exhaust valve closes (at 1 mm lift)		-5° ATDC
	Lubrication system		Forced pressure and wet sump
	Oil pump type		Trochoid
	Cooling system		Liquid cooled
	Air filtration		Paper filter
	Crankshaft type		Unit-type, 4 main journal
	Engine dry weight		80.3 kg (177 lbs)
Firing order		1 - 90° - 4 - 270° - 3 - 90° - 2 - 270° - 1	
Cylinder arrangement		4 cylinder 90° V	
Cylinder number			

General (Cont'd)		
	Item	Specifications
<b>Carburetor</b>	Carburetor type Venturi diameter	CV (Constant Velocity) type, with flat valve 33 mm (1.30 in)
<b>Drive Train</b>	Clutch system Clutch operation system Transmission Primary reduction Secondary reduction Third reduction Final reduction Gear ratio 1st Gear ratio 2nd Gear ratio 3rd Gear ratio 4th Gear ratio 5th Gear ratio 6th Gear ratio reverse Gearshift pattern	Multi-plate, wet Cable operating 5 speeds 1.939 (64/33) — — 2.500 (40/16) 2.846 (37/13) 1.882 (32/17) 1.450 (29/20) 1.227 (27/22) 1.035 (29/28) — — Left foot operated return system 1—N—2—3—4—5
<b>Electrical</b>	Ignition system Starting system Charging system Regulator/rectifier type Lighting system AC regulator type	Full transistor ignition Starter motor Triple phase output alternator SCR shorted/triple phase, full-wave rectification Battery —



# General Information



Unit: mm (in)

Lubrication	Item	Standard	Service Limit
	Engine oil capacity at draining at disassembly at oil filter change	3.0 lit (3.2 US qt, 2.6 Imp qt) 3.8 lit (4.0 US qt, 3.3 Imp qt) 3.1 lit (3.3 US qt, 2.7 Imp qt)	— — —
	Recommended engine oil	Use Honda GN4 4-stroke Oil or equivalent API Service Classification: SF or SG Viscosity: SAE 10W-40	
	<p><b>OIL VISCOSITIES</b></p> <p>Oil pressure at oil pressure switch</p>	<p>Other viscosities shown in the chart may be used when the average temperature in your riding area is within the indicated range.</p> <p>490-588 kPa (5-6 kg/cm<sup>2</sup>, 71.1-85.3 psi) at 6,000 rpm (80°C/176°F)</p>	
	Oil pump rotor tip clearance ① body clearance ② end clearance ③	0.10 (0.004) 0.15-0.22 (0.006-0.009) 0.02-0.09 (0.001-0.004)	0.15 (0.006) 0.35 (0.014) 0.10 (0.005)

Fuel System	Item	Standard	Service Limit
	Carburetor identification number (49 states type) (California type) (Canadian type)	VP31A VP30A VP32D	— — —
	Main jet	#102	—
	Slow jet	#40	—
	Pilot screw initial opening	see page 5-16	—
	Pilot screw high altitude adjustment	see page 5-17	—
	Float level	13.7 (0.54)	—
	Carburetor vacuum difference	Within 20 mmHg (0.8 inHg)	—
	Base carburetor (For carburetor synchronization)	No. 1 carburetor	—
	Idle speed (49 states type)	1,000 ± 100 rpm	—
	(California type)	1,100 ± 100 rpm	—
	(Canadian type)	1,000 ± 100 rpm	—
	Throttle grip free play	2-6 (1/8-1/4)	—
	Pulse secondary air (PAIR) injection system (California type)	PAIR check valves are built in to the PAIR control valve	—
	Pulse secondary air injection control valve vacuum pressure	—	—

Cooling System	Item	Standard	Service Limit
	Cooling capacity (Radiator and engine) (Reserve tank)	2.4 ℓ (0.6 US gal, 0.5 Imp gal) 0.4 ℓ (0.1 US gal, 0.09 Imp gal)	— —
	Radiator cap relief pressure	107.9 kPa (1.1 kg/cm <sup>2</sup> , 15.64 psi)	—
	Thermostat begins to open	80-84°C (176-183°F)	—
	Thermostat fully open	95°C (203°F)	—
	Thermostat valve lift	8.0 (0.315) min.	—

Unit: mm (in)

Cylinder Head Item	Standard	Service Limit
Cylinder compression	1,275 kPa (184.9 psi, 13.0 kg/cm <sup>2</sup> )/ 500 rpm	—
Cylinder compression synchronization difference	—	—
Valve clearance IN	0.16 ± 0.02 (0.006 ± 0.001)	—
EX	0.25 ± 0.02 (0.010 ± 0.001)	—
Cylinder head warpage	—	0.10 (0.004)
Cam lobe height ① IN	35.980—36.140 (1.4165—1.4228)	35.95 (1.4153)
IN (California type)	—	—
EX (California type)	35.670—35.830 (1.4043—1.4106)	35.64 (1.4031)
EX (California type)	—	—
Camshaft runout ②	—	0.05 (0.002)
Camshaft oil clearance	0.030—0.072 (0.0012—0.0028)	0.10 (0.004)
		
Camshaft journal O.D.	24.949—24.970 (0.9822—0.9831)	24.94 (0.982)
Camshaft holder I.D.	25.000—25.021 (0.9843—0.9851)	25.05 (0.986)
Valve stem O.D. IN	4.475—4.490 (0.1762—0.1767)	4.46 (0.175)
EX	4.465—4.480 (0.4758—0.1764)	4.45 (0.175)
Valve guide I.D. IN	4.500—4.512 (0.1772—0.1776)	4.56 (0.179)
EX	4.500—4.512 (0.1772—0.1776)	4.56 (0.179)
Stem-to-guide clearance IN	0.010—0.037 (0.0004—0.0015)	—
EX	0.020—0.047 (0.0008—0.0019)	—
Valve guide projection above cylinder head IN	15.30—15.50 (0.602—0.610)	—
EX	15.30—15.50 (0.602—0.610)	—
 <p data-bbox="357 1134 763 1302">Before guide installation: 1. Chill the valve guides in the freezer section of the refrigerator for about an hour. 2. Heat the cylinder head to 212—300°F (100—150°C)</p>		
Valve seat width	1.0 (0.04)	1.5 (0.06)
Valve spring free length	37.86 (1.49)	36.1 (1.42)
Valve lifter O.D.	25.978—25.993 (1.0225—1.0233)	25.96 (1.022)
Valve lifter bore I.D.	26.010—26.026 (1.0240—1.0246)	26.04 (1.025)

# General Information



Unit: mm (in)

Clutch System		Standard	Service Limit
Clutch lever free play		10–20 (0.4–0.8)	—
Clutch outer guide I.D.		24.995–25.012 (0.9841–0.9847)	25.08 (0.987)
Clutch spring free length		44.4 (1.75)	41.2 (1.62)
Clutch disc thickness A		2.92–3.08 (0.115–0.121)	2.5 (0.10)
	B (Judder spring side)	2.92–3.08 (0.115–0.121)	2.5 (0.10)
Clutch palte warpage		—	—

Cylinder/Piston		Standard	Service Limit
Cylinder I.D.		70.000–70.015 (2.755–2.756)	70.10 (2.759)
Cylinder out of round		—	0.10 (0.004)
Cylinder taper		—	0.10 (0.004)
Cylinder warpage		—	0.10 (0.004)
Piston mark direction		With "IN" mark facing to the intake side	—
Piston O.D. (D)		69.970–69.990 (2.755–2.756)	69.85 (2.750)
Piston O.D. measurement point (H)		10 (0.4)	—
Piston pin hole O.D. (d)		17.002–17.008 (0.6694–0.6695)	17.02 (0.670)
Cylinder-to-piston clearance		0.010–0.035 (0.0004–0.0014)	—
Piston pin O.D.		16.994–17.000 (0.6691–0.6693)	16.98 (0.669)
Piston-to-piston pin clearance		0.002–0.014 (0.0001–0.0005)	—
Connecting rod-to-piston clearance		0.016–0.040 (0.0006–0.0016)	—
Top ring-to-ring groove clearance		0.015–0.050 (0.0006–0.0019)	0.10 (0.04)
Second ring-to-ring groove clearance		0.015–0.045 (0.0006–0.0018)	0.10 (0.004)
Top ring end gap		0.20–0.35 (0.008–0.014)	0.5 (0.02)
Second ring end gap		0.35–0.50 (0.014–0.020)	0.7 (0.03)
Oil ring (side rail) end gap		0.20–0.80 (0.008–0.031)	1.00 (0.039)
Top ring mark		Install with the marked side up	—
Second ring mark		Install with the marked side up	—

Crankshaft		Standard	Service Limit
Connecting rod small end I.D.		17.016–17.043 (0.6699–0.6706)	17.04 (0.671)
Connecting rod big end side clearance radial clearance		0.10–0.30 (0.004–0.012)	0.40 (0.016)
Crankshaft runout (1)		—	0.05 (0.002)
Crankpin oil clearance		0.030–0.052 (0.0012–0.0020)	0.08 (0.003)
Connecting rod bearing selection		See page 11-9	—
Main journal oil clearance		0.019–0.037 (0.0007–0.0015)	0.05 (0.019)
Main journal bearing selection		See page 11-8	—

Unit: mm (in)

Transmission	Item	Standard	Service Limit
	Transmission gear I.D. M5	28.000–28.021 (1.1024–1.1032)	28.04 (1.104)
	C2	31.000–31.016 (1.2205–1.2211)	31.04 (1.222)
	C3	31.000–31.016 (1.2205–1.2211)	31.04 (1.222)
	C4	31.000–31.016 (1.2205–1.2211)	31.04 (1.222)
	Transmission gear bushing O.D. M5	27.959–27.980 (1.1007–1.1016)	27.94 (1.010)
	C2	30.970–30.995 (1.2193–1.2203)	30.95 (1.219)
	C3	30.950–30.975 (1.2185–1.2195)	30.93 (1.218)
	C4	30.950–30.975 (1.2185–1.2195)	30.93 (1.218)
	Transmission gear bushing I.D. M5	24.985–25.006 (0.9834–0.9845)	27.94 (1.010)
	C2	28.000–28.021 (1.1024–1.1032)	28.04 (1.104)
	C3	27.995–28.016 (1.1022–1.1029)	28.04 (1.104)
	Gear-to-bushing clearance at M5 gear	0.020–0.062 (0.0008–0.0024)	—
	at C2 gear	0.005–0.046 (0.0002–0.018)	—
	at C3 gear	0.025–0.066 (0.0001–0.0026)	—
	at C4 gear	0.025–0.066 (0.0001–0.0026)	—
	Mainshaft O.D. at M5 gear bushing	24.959–24.980 (0.9826–0.9835)	24.95 (0.982)
			
	Countershaft O.D. at C2 gear bushing	27.967–27.980 (1.1011–1.1016)	27.96 (1.101)
			
	Gear-to-shaft clearance	—	—
	Gear bushing-to-shaft clearance at M5 gear	0.005–0.047 (0.0002–0.0019)	—
	at C2 gear	0.020–0.054 (0.0008–0.0021)	—
	at C3 gear	0.015–0.049 (0.0006–0.0019)	—
	at C4 gear	0.015–0.049 (0.0006–0.0019)	—
	Shift fork claw thickness L	6.43–6.50 (0.253–0.256)	6.40 (0.252)
	C	6.43–6.50 (0.253–0.256)	6.40 (0.252)
	R	6.43–6.50 (0.253–0.256)	6.40 (0.252)
	Shift fork I.D. L	14.016–14.034 (0.5518–0.5525)	14.043 (0.5529)
	C	14.016–14.034 (0.5518–0.5525)	14.043 (0.5529)
	R	14.016–14.034 (0.5518–0.5525)	14.043 (0.5529)
	Shift fork shaft O.D.	13.973–13.984 (0.5501–0.5506)	13.965 (0.5498)


## General Information

Unit: mm (in)

Wheel/Tires	Item	Standard	Service Limit
	Minimum tire tread depth (FR) (RR)	— —	1.5 (0.06) 2.0 (0.08)
	Cold tire pressure Up to 90 kg (200 lb) load (FR)	250 kPa (2.50 kg/cm <sup>2</sup> , 36 psi)	—
	Up to 90 kg (200 lb) load (RR)	250 kPa (2.50 kg/cm <sup>2</sup> , 36 psi)	—
	Up to maximum weight capacity (FR)	250 kPa (2.50 kg/cm <sup>2</sup> , 36 psi)	—
	Up to maximum weight capacity (RR)	290 kPa (2.90 kg/cm <sup>2</sup> , 42 psi)	—
	Front and rear axle runout	—	0.2 (0.01)
	Front and rear wheel rim runout (Radial)	—	2.0 (0.08)
	(Axial)	—	2.0 (0.08)
	Wheel balance weight (Front)	—	60 g (2.1 oz)
	(Rear)	—	60 g (2.1 oz)
	Drive chain slack	20–30 (3/4–1•3/16)	—
	Drive chain size/link (DID)	DID 50V4/118	—
	(RK)	RK 50 MFOZ1/118	—

Front Suspension			
	Fork spring free length	410.7 (16.17)	402.5 (15.85)
	Fork spring direction	Tapered coil facing down	—
	Fork tube runout	—	0.2 (0.01)
	Recommended fork oil	Fork fluid	—
	Fork oil level	122 (4.80)	—
	Fork oil capacity	521cc (17.62 US oz, 18.29 Imp oz)	—
	Steering bearing preload	0.1–0.15 kg-m	—

Rear Suspension			
	Shock absorber spring free length	241.8 (9.52)	237.0 (9.33)
	Shock absorber spring adjuster standard position	2nd groove	—
	Shock absorber spring direction	Small coil end facing down	—

Brakes			
Front	brake fluid	DOT 4	—
	brake pad wear indicator ①	—	To the groove
			
Rear	brake disc thickness	6.0 (0.24)	5.0 (0.20)
	brake disc runout	—	0.25 (0.01)
	master cylinder I.D.	11.0–11.043 (0.4331–0.4348)	11.055 (0.4352)
	master piston O.D.	10.957–10.984 (0.4314–0.4324)	10.945 (0.4309)
	caliper cylinder I.D.	25.400–25.450 (1.000–1.0020)	25.461 (1.002)
	caliper piston O.D.	25.335–25.368 (0.9974–0.9987)	25.33 (0.997)
	brake pedal free play	20–30 (0.8–1.2)	—
	brake drum I.D.	180–180.3 (7.086–7.098)	181 (7.12)
	brake lining thickness	5.0 (0.2)	2.0 (0.08)

Unit: mm (in)

Battery/Charging System		
Item	Standard	Service Limit
Alternator/charging coil resistance (at 20°C/68°F)	0.1 – 1.0 Ω	—
Regulator/rectifier regulated voltage/amperage	14 – 15.5 V/below 0.5 A/3,000 rpm	—
Battery capacity	12 V – 10 Ah	—
Battery charging rate (Normal)	1.2 A (5 – 10h)	—
(Quick)	5 A (1h)	—
Battery voltage (fully charged 20°C/68°F)	Over 13.1 V	—
(needs charging 20°C/68°F)	Below 12.5 V	—

Ignition System		
Spark plug		
(Standard NGK)	CR8EH9	—
(Standard NIPPONDENSO)	U24FER9	—
(For cold climate/below 5°C/41°F NGK)	—	—
(For cold climate/below 5°C/41°F NIPPONDENSO)	—	—
(For extended high speed riding NGK)	CR9EH9	—
(For extended high speed riding NIPPONDENSO)	U27FER9	—
Spark plug gap	0.8 – 0.9 (0.03 – 0.04)	—
Ignition timing "F" mark	12° BTDC at idle	—
Advance start	2,000 rpm	—
stop	—	—
Full advance	—	—
Ignition coil resistance (Primary: at 20°C/68°F)	2 – 4 Ω	—
(Secondary with plug cap)	23 – 27 kΩ	—
(Secondary without plug wire)	13 – 17 kΩ	—
Pulse generator resistance (At 20°C/68°F)	450 – 550 Ω	—

Starter System		
Starter motor brush length	12.0 – 13.0 (0.47 – 0.51)	6.5 (0.26)
Starter clutch driven gear O.D.	47.175 – 47.200 (1.8573 – 1.8583)	47.16 (1.857)

Lights/Meters/Switches		
Main fuse	30 A	—
Fuse	10 A x 3, 15 A x 1	—
Headlight (high/low beam)	12 V 60/55 W	—
Tail/brake light	12 V 32/3 cp	—
Position light bulb	12 V 3 cp x 2	—
Front turn signal lights	12 V 32/3 cp x 2	—
Rear turn signal lights	12 V 32 cp x 2	—
Instrument lights	12 V 1.7 W x 1, 12 V 1.4 W x 2	—
Oil pressure warning indicator	12 V 3 W	—
Side stand indicator	12 V 3 W	—
Coolant temperature indicator	12 V 3 W	—
High beam indicator	12 V 3 W	—
Turn signal indicator	12 V 3 W	—
Neutral indicator	12 V 3 W	—
Coolant temperature sensor resistance	85°C (185°F) 39 – 49 Ω	—
	120°C (248°F) 14 – 18 Ω	—
Fan motor switch	Starts to close (ON) 97 – 103°C (207 – 217°F)	—
	Stops to open (OFF) 92 – 98°C (198 – 208°F)	—

General Information

Torque Values

Standard			
Fasteners Type	Torque N·m (kg-m, ft-lb)	Fasteners Type	Torque N·m (kg-m, ft-lb)
5 mm hex bolt and nut	5 (0.5, 3.5)	5 mm screw	4 (0.4, 3)
6 mm hex bolt and nut	10 (1.0, 7)	6 mm screw	9 (0.9, 7)
8 mm hex bolt and nut	22 (2.2, 16)	6 mm flange bolt (8 mm head)	9 (0.9, 7)
10 mm hex bolt and nut	35 (3.5, 25)	6 mm flange bolt (10 mm head) and nut	12 (1.2, 9)
12 mm hex bolt and nut	55 (5.5, 40)	8 mm flange bolt and nut	27 (2.7, 20)
		10 mm flange bolt and nut	40 (4.0, 29)

Torque specifications listed below are for important fasteners. Others should be tightened to standard torque values listed above.

- Notes:
1. Apply sealant to the threads.
  2. Apply a locking agent to the threads.
  3. Apply molybdenum disulfide oil to the threads and flange surface.
  4. Left hand threads.
  5. Stake.
  6. Apply oil to the threads and flange surface.
  7. Apply clean engine oil to the O-ring.
  8. Torque wrench scale reading using a special tool.
  9. Apply grease to the threads and flange surface.
  10. UBS bolt.
  11. U-nut.
  12. ALOC bolt; Replace with a new one.

Engine				
Item	Q'ty	Thread dia. (mm)	Torque N·m (kg-m, ft-lb)	Remarks
<b>Maintenance:</b>				
Timing hole cap	1	45	18 (1.8, 13)	Note 9
<b>Lubrication:</b>				
Oil pressure switch	1	PT 1/8	12 (1.2, 9)	Note 1
Oil filter	1	20	10 (1.0, 7)	Note 6
Oil filter stud bolt	1	20	18 (1.8, 13)	Note 2
Oil drain bolt	1	12	34 (3.4, 25)	
Oil pump bolt	3	6	13 (1.3, 9)	
Oil pump driven sprocket bolt	1	6	18 (1.8, 13)	Note 2
Oil pipe nut (After '94)	1	6	12 (1.2, 9)	Note 11
<b>Fuel Systems:</b>				
Connecting tube band screw	4	5	1 (0.1, 0.7)	
<b>Cooling Systems:</b>				
Water pump cover	2	6	13 (1.3, 9)	
Water pump mounting bolt	2	6	13 (1.3, 9)	
<b>Cylinder Head:</b>				
Spark plug	4	10	12 (1.2, 9)	
Head cover protector	8	6	10 (1.0, 7)	
Cylinder head cover bolt	8	6	10 (1.0, 7)	
Breather case bolt	6	6	10 (1.0, 7)	
Cylinder head protector bolt	12	6	12 (1.2, 9)	
Cylinder head sealing bolt	4	18	44 (4.4, 32)	Note 2
Cylinder head bolt (9 mm)	16	9	44 (4.4, 32)	Note 6
Cylinder head bolt (6 mm)	4	6	12 (1.2, 9)	
Camshaft holder bolt	32	6	12 (1.2, 9)	Note 6
Cam chain tensioner mounting bolt	4	6	12 (1.2, 9)	
Boost joint bolt	—	5	4 (0.4, 2.9)	

Engine				
Item	Q'ty	Thread dia. (mm)	Torque N·m (kg-m, ft-lb)	Remarks
<b>Clutch/Gearshift Linkage</b>				
Right crankcase cover bolt	13	6	12 (1.2, 9)	
Clutch cable holder bolt	1	10	23 (2.3, 17)	
Clutch spring bolt	5	6	12 (1.2, 9)	
Clutch center lock nut ('94)	1	22	90 (9.0, 65)	Note 5, 6
(After '94)	1	22	110 (11.0, 80)	Note 5, 6
Gearshift link joint bolt	1	6	9 (0.9, 6.5)	
Change pedal pivot bolt	1	8	27 (2.7, 20)	
Drive sprocket cover bolt	3	6	10 (1.0, 7)	
Drive sprocket cover rubber bolt	2	6	12 (1.2, 9)	
Drive sprocket bolt	1	10	51 (5.1, 37)	
Shift drum center bolt	1	8	23 (2.3, 17)	Note 2
Shift return spring pin	1	8	23 (2.3, 17)	
<b>Crankcase/Crankshaft:</b>				
Upper crankcase bolt (10 mm)	2	10	39 (3.9, 28)	
Upper crankcase bolt (6 mm)	7	6	12 (1.2, 9)	
Lower crankcase bolt (9 mm)	8	9	31 (3.1, 22)	Note 6
Lower crankcase bolt (8 m)	1	8	23 (2.3, 17)	
Lower crankcase bolt (6 mm)	8	6	12 (1.2, 9)	
Cam chain tensioner slipper bolt	2	6	12 (1.2, 9)	Note 2
Cam chain slipper bolt	2	6	12 (1.2, 9)	Note 2
Connecting rod bearing cap nut	8	8	33 (3.3, 24)	Note 6
Sealing bolt	1	8	18 (1.8, 13)	Note 2
<b>Alternator:</b>				
Left crankcase cover bolt	6	6	12 (1.2, 9)	
Flywheel bolt	1	10	83 (8.3, 61)	Note 6
Stator mounting bolt	3	6	12 (1.2, 9)	
<b>Ignition System:</b>				
Pulse generator mounting bolt	3	6	10 (1.0, 7)	
<b>Starter Clutch:</b>				
Starter motor flange nut	1	6	10 (1.0, 7)	
Starter motor case bolt	2	5	5 (0.5, 3.6)	
Starter clutch bolt	1	12	90 (9.0, 65)	Note 6
Starter clutch outer cover bolt	3	8	40 (4.0, 29)	Note 2
<b>Lights/Meters/Switches:</b>				
Neutral switch	1	10	12 (1.2, 9)	

Frame				
Item	Q'ty	Thread dia. (mm)	Torque N·m (kg-m, ft-lb)	Remarks
<b>Engine mounting:</b>				
Front cylinder head mounting bolt	2	10	54 (5.4, 39)	
Front engine mounting bracket bolt	4	8	39 (3.9, 28)	
Front engine mounting bolt	2	10	44 (4.4, 32)	
Rear engine mounting bracket bolt	2	8	39 (3.9, 28)	
Rear engine mounting bolt	1	12	64 (6.4, 46)	Note 9
Rear cylinder head mount bolt	2	10	44 (4.4, 32)	
Rear cylinder head mount bracket bolt	4	8	39 (3.8, 28)	



## General Information

Frame	Item	Q'ty	Thread dia. (mm)	Torque N·m (kg-m, ft-lb)	Remarks
<b>Front Suspension:</b>					
	Handlebar upper holder bolt	4	6	23 (2.3, 17)	
	Front fender bolt	4	6	12 (1.2, 9)	
	Steering stem nut	1	24	105 (10.5, 76)	page 12-12
	Lock nut	1	26	—	
	Steering head bearing adjusting nut	1	26	30 (3.0, 22)	
	Fork pinch bolt (upper)	2	8	27 (2.7, 20)	
	(lower)	2	10	39 (3.9, 28)	
	Fork cap	2	37	23 (2.3, 17)	
	Fork socket bolt	2	8	20 (2.0, 14)	Note 2
	Fork drain bolt	2	6	8 (0.8, 5.8)	
<b>Rear Suspension:</b>					
	Frame pivot adjusting bolt	1	20	15 (1.5, 11)	page 13-10
	Frame lock nut	1	20	64 (6.4, 46)	
	Frame lock bolt	1	10	39 (3.9, 28)	
	Swingarm pivot nut	1	14	89 (8.9, 65)	Note 11
	Chain slider screw	2	5	6 (0.6, 4.3)	
	Chain tensioner	2	8	22 (2.2, 16)	
	Shock absorber mounting bolt (upper)	2	8	27 (2.7, 20)	
	(lower)	2	10	37 (3.7, 27)	
<b>Wheels:</b>					
	Speedometer cable screw	1	5	4 (0.4, 2.9)	
	Rear axle nut	1	18	93 (9.3, 63)	Note 11
	Front axle bolt	1	14	59 (5.9, 43)	
	Axle pinch bolt	4	8	22 (2.2, 16)	
	Brake disc bolt	6	8	42 (4.2, 30)	Note 12
	Driven sprocket nut	5	12	108 (10.8, 79)	Note 11
<b>Brake System:</b>					
	Brake hose bolt	2	10	35 (3.5, 25)	
	Caliper bracket bolt	2	8	31 (3.1, 22)	Note 12
	Front brake hose clamp nut	2	6	12 (1.2, 9)	Note 11
	Front master cylinder holder bolt	2	6	12 (1.2, 9)	
	Front master cylinder reservoir cover screw	2	4	1.5 (0.15, 1.1)	
	Front brake light switch screw	1	4	1.2 (0.12, 0.9)	
	Front brake lever pivot bolt	1	6	1 (0.1, 0.7)	
	nut	1	6	6 (0.6, 4.3)	
	Pad pin plug	1	10	2.5 (0.25, 1.8)	
	Pad pin	1	10	18 (1.8, 13)	
	Brake caliper bleeder bolt	1	8	5.5 (0.55, 4)	
	Brake caliper bracket pin bolt	1	8	13 (1.3, 9)	Note 2
	Brake caliper pin bolt	1	8	23 (2.3, 17)	Note 2
	Rear brake pedal pivot bolt	1	10	39 (3.9, 28)	
	Rear brake pedal linkage joint pinch bolt	1	8	27 (2.7, 20)	
	Rear brake arm pinch bolt	1	8	29 (2.9, 21)	Note 12
	Rear brake stopper arm nut	2	8	22 (2.2, 16)	
<b>Frame/Exhaust Systems:</b>					
	Exhaust pipe joint nut	8	8	12 (1.2, 9)	
	Exhaust pipe band bolt	4	8	21 (2.1, 15)	
	Exhaust pipe protector bolt	6	6	12 (1.2, 9)	
	Muffler mounting bolt	2	8	27 (2.7, 20)	
<b>Lights/Meters/Switches:</b>					
	Side stand pivot bolt	1	10	10 (1.0, 7)	
	nut	1	10	30 (3.0, 22)	
	Side stand switch	1	6	10 (1.0, 7)	
<b>Others:</b>					
	Footpeg bracket bolt	4	8	27 (2.7, 20)	
	Fuel valve	1	22	23 (2.3, 17)	




## Tools

Description	Tool Number	Applicability
<b>Maintenance:</b>		
Oil filter wrench	07HAA—PJ70100	
Drive chain cutter	07HMH—MR10102 or 07HMH—MR1010B	U.S.A. only
Link plate holder	07NMH—MW00110 or 07PMH—MZ20110	
<b>Lubrication:</b>		
Oil pressure gauge	07506—3000000	
Oil pressure gauge attachment	07510—4220100	
<b>Fuel System:</b>		
Float level gauge	07401—0010000	
Pilot screw wrench (Canadian type) (49 states, California type)	07908—4220201 07MMA—MV9010A	
<b>Cylinder Head/Cylinder/Piston:</b>		
Valve spring compressor	07757—0010000	
Valve spring compressor attachment	07959—KM30101	
Tappet hole protector	07HMG—MR70002	Not available in U.S.A.
Valve guide driver	07HMD—ML00101	
Valve guide reamer, 4.5 mm	07HMH—ML00101	
Valve seat cutter		
seat cutter, 24.5 mm (45° EX)	07780—0010100	
29 mm (45° IN)	07780—0010300	
flat cutter, 25 mm (32° EX)	07780—0012000	
30 mm (32° IN)	07780—0012200	
interior cutter, 26 mm (60° EX)	07780—0014500	
30 mm (60° IN)	07780—0014000	
cutter holder, 4.5 mm	07781—0010600	
Compression gauge attachment	07JMJ—KY20100	
Tensioner stopper	07NMG—MY90100	Not available in U.S.A.
<b>Clutch/Gearshift Linkage:</b>		
Lock nut wrench, 26 x 30 mm	07716—0020203	'94 only
Extension bar	07716—0020500	'94 only
Clutch center holder	07724—0050001	Equivalent commercially available in U.S.A.
<b>Crankshaft/Transmission:</b>		
Universal bearing puller	07631—0010000	
Inner driver C	07746—0030100	
Attachment, I.D. 25 mm	07746—0030200	
<b>Front Wheel/Suspension/Steering:</b>		
Bearing remover shaft	07746—0050100	
Bearing remover head, 20 mm	07746—0050600	
Attachment, 42 x 47 mm	07746—0010300	
Pilot, 20 mm	07746—0040500	
Fork seal driver	07947—KA50100	
Fork seal driver attachment	07947—KF00100	
Steering stem socket wrench	07916—3710101	
Ball race remover	07953—MJ10000	
— attachment	07953—MJ10100	
— driver handle	or 07953—MJ1000A 07953—MJ10200	U.S.A. only
Ball race remover	or M9360—277—91774	U.S.A. only
Attachment, 52 x 55 mm	07946—3710500	
Steering stem driver	07746—0010400	
Driver	07946—MB00000 07749—0010000	

## General Information

Description	Tool Number	Applicability
<b>Rear Wheel/Suspension:</b>		
Bearing remover shaft	07746-0050100	
Bearing remover head, 20 mm	07746-0050600	
Attachment, 42 x 47 mm	07746-0010300	
Pilot, 20 mm	07746-0040500	
Attachment, 52 x 55 mm	07746-0010400	
Attachment, 62 x 68 mm	07746-0010500	
Pilot, 25 mm	07746-0040600	
Shock absorber compressor	07959-3290001	
Driver shaft	07946-MJ00100	
	or 07949-3710001	U.S.A. only
Attachment, 28 x 30 mm	07946-1870100	
Pilot, 22 mm	07746-0041000	
Attachment, 32 x 35 mm	07746-0010100	
Pilot, 15 mm	07746-0040300	
Needle bearing remover attachment	07GMD-KT70200	
Bearing remover	or M967X-038-XXXXX	U.S.A. only
Attachment, 30 mm	07746-0030300	U.S.A. only
Driver	07749-0010000	
<b>Brake:</b>		
Snap ring pliers	07914-3230001	
<b>Charging System/Alternator:</b>		
Flywheel holder	07725-0040000	
Rotor puller	07733-0020001	
<b>Electric Starter/Starter Clutch:</b>		
Gear holder	07724-0010100	
<b>Electrical Equipment:</b>		
Digital multimeter (KOWA)	07411-0020000	Equivalent commercially available in U.S.A.
Analog tester	07308-0020001 (SANWA) or TH-5H (KOWA)	Not available in U.S.A.

# Lubrication & Seal Points



Engine	Location	Material	Remarks
<p>Crankcase mating surface</p>  <p>Right crankcase cover mating surface</p> <p>20–30 mm (0.8–1.2 in)</p>  <p>Left crankcase cover mating surface</p> <p>20–30 mm (0.8–1.2 in)</p>  <p>Cylinder head semi-circular cut-out</p>	<p>Liquid sealant</p>	<ul style="list-style-type: none"> <li>• Wipe off the excess sealant</li> <li>• Do not apply the sealant to near the bearing</li> </ul>	
<p>Crankshaft main bearing thrust surface</p> <p>Connecting rod big end bearing small end</p> <p>Valve stem (valve guide sliding surface)</p> <p>Valve lifter outer sliding surface</p> <p>Camshaft lobes/journals</p> <p>M3/4, C5 and shifter gear (shift fork grooves)</p> <p>Shift fork shaft sliding area</p> <p>Shift drum</p> <p>Primary drive gear sliding area</p> <p>Each gear</p>	<p>Molybdenum disulfide oil (A mixture of 1/2 engine oil and 1/2 molybdenum disulfide grease)</p>		
<p>Cylinder head cover gasket mating surface (cover side)</p>	<p>Honda Bond A</p>		


## General Information

Engine		
Location	Material	Remarks
Right crankcase cover rubber plate bolt threads Drive chain guard bolt threads Crankcase sealing bolt threads Oil pump driven sprocket bolt threads Cam chain tensioner slipper bolt threads Cam chain slipper bolt threads Mainshaft bearing set plate bolt threads Shift drum bearing set plate bolt threads Shift drum center bolt Starter clutch outer cover bolt Oil filter stud bolt threads Cylinder head sealing bolt threads	Locking agent	Clean and apply to the threads Apply area: 5.5--7.5 mm
Oil pressure switch threads Thermo sensor threads	Liquid sealant	
Lower crankcase bolt (9 mm) threads Cylinder head bolt (9 mm) threads and flange surface Camshaft holder bolt (6 mm) threads and flange surface Piston sliding surface pin hole ring Connecting rod bolt and nut threads Starter clutch bolt threads and seating surface Flywheel bolt threads and seating surface Oil filter threads Clutch disc lining surface Clutch center lock nut Each bearing	Engine oil	
Clutch lifter guide Timing hole cap threads Each oil seal lips Each O-ring	Multi-purpose grease	


Frame	Location	Material	Remarks
	Side stand pivot bolt sliding surface Rear brake pedal linkage sliding surface Rear brake pedal pivot surface Rear brake spindle sliding surface Right/left footpeg sliding surface Gearshift pedal pivot surface Throttle pipe sliding surface Clutch lever pivot bolt sliding surface Steering head bearings Steering head bearing dust seal lips Swingarm pivot nut flange surface Swingarm bearings Swingarm dust seal lips Front wheel dust seal lips Rear wheel dust seal lips Rear wheel sliding surface (driven flange) Rear engine mounting nut threads and seating surface Each bearing Each dust seal lips	Multi-purpose grease	Apply thin coat of grease
	Throttle cables Choke cable Clutch cable Speedometer cable Steering stem lock nut threads Flywheel bolt threads and flange surface	Engine oil	
	Handle grip inner surface	Honda Bond A	Honda Hand Grip Cement (U.S.A. only)
	Front brake lever pivot and piston tips Brake caliper pin bolt sliding surface Brake caliper bracket pin bolt sliding surface Brake cam sliding surface Brake anchor pin sliding surface	Silicone grease	
	Brake caliper pin bolt threads Brake caliper bracket pin bolt threads Fork socket bolt threads	Locking agent	Clean and apply to the threads
	Front fork oil seal/dust seal lips Front fork	Fork fluid	
	Brake master cylinder	DOT 4 brake fluid	


## Cable & Harness Routing





















## Emission Control System

The U.S. Environmental Protection Agency and California Air Resources Board (CARB) require manufacturers to certify that their motorcycles comply with applicable exhaust emissions standard during their useful life, when operated and maintained according to the instructions provided, and that motorcycles built after January 1, 1983 comply with applicable noise emission standards for 1 year or 6,000 km (3,730 miles) after the time of sale to the ultimate purchaser, when operated and maintained according to the instructions provided. Compliance with the terms of the Distributor's Warranties for Honda Motorcycle Emission Control Systems is necessary in order to keep the emissions system warranty in effect.


### Source Of Emissions

The combustion process produces carbon monoxide and hydrocarbons. Control of hydrocarbons is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Honda Motor Co., Ltd. utilizes lean carburetor settings as well as other systems, to reduce carbon monoxide and hydrocarbons.

### Crankcase Emission Control System

The crankcase emission control system routes crankcase emissions through the air cleaner and into the combustion chamber.



## General Information

---

### Exhaust Emission Control System (Pulse Secondary Air Injection System)

#### California type only

The exhaust emission control system consists of a pulse secondary air injection system which introduces filtered air into the exhaust gases in the exhaust port. Fresh air is drawn into the exhaust port whenever there is a negative pressure pulse in the exhaust system. This charge of fresh air promotes burning of the unburned exhaust gases and changes a considerable amount of hydrocarbons and carbon monoxide into relatively harmless carbon dioxide and water vapor.

This model has two pulse secondary air injection control valves with built-in check valves. The PAIR check valves prevent reverse air flow through the system. The pulse secondary air injection control valve reacts to high intake manifold vacuum and will cut off the supply of fresh air during engine deceleration, thereby preventing afterburn in the exhaust system.

No adjustments to the secondary air supply system should be made, although periodic inspection of the components is recommended.


(1) FRONT PULSE SECONDARY AIR INJECTION (PAIR)  
CONTROL VALVE

(2) AIR CLEANER

(5) PAIR CHECK  
VALVES

(3) INTAKE PORT


(4) EXHAUST PORT



## Evaporative Emission Control System (California Type Only)

This vehicle complies with the California Air Resources Board requirements for control of evaporative emissions.

Fuel vapor from the fuel tank and carburetor is routed into the evaporative emission canister where it is absorbed and stored while the engine is stopped. When the engine is running and the evaporative emission purge control diaphragm valve is open fuel vapor in the evaporative emission canister is drawn into the engine through the carburetor. At the same time, the evaporative emission carburetor air vent control valve is open and air is drawn into the carburetor through the valve.



## Noise Emission Control System

**TAMPERING WITH THE NOISE CONTROL SYSTEM IS PROHIBITED:** Federal law prohibits the following acts or the causing thereof: (1) the removal or rendering inoperative by any person, other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.


**Among those acts presumed to constitute tampering are the acts listed below:**

1. Removal of, or puncturing the muffler, baffles, header pipes or any other component which conducts exhaust gases.
2. Removal of, or puncturing of any parts of the intake system.
3. Lack of proper maintenance.
4. Replacing any moving parts of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.



## Emission Control Information labels (U.S.A. Only)


An Emission Information Label is located on the frame as shown. The right side cover must be removed to view it. It gives basic tune-up specifications.



## Vehicle Emission Control Information Update Label

After making a high altitude carburetor adjustment, attach an update label on the right down tube as shown.

After re-adjusting the carburetor back to standard settings for low altitude, remove the update label.





## Vacuum Hose Routing Diagram Label (California Type Only)

The Vacuum Hose Routing Diagram Label is on the rear fender as shown.

The seat must be removed to view it.

Route the vacuum hoses as shown on this label.



---

## 2. Frame/Body Panels/Exhaust System

2

Service Information	2-1	Front Side Cover Removal/Installation	2-3
Troubleshooting	2-1	Exhaust System Removal/Installation	2-4
Seat Removal/Installation	2-2	Rear Fender Removal/Installation	2-7
Fuel Tank Removal/Installation	2-2	Upper Fairing Removal/Installation (VF750CD)	2-8
Side Cover Removal/Installation	2-3		

### Service Information

#### **⚠ WARNING**

- Gasoline is extremely flammable and is explosive under certain conditions. KEEP OUT OF REACH OF CHILDREN.
- Serious burns may result if the exhaust system is not allowed to cool before components are removed or serviced.

- Work in a well ventilated area. Smoking or allowing flames or sparks in the working area or where gasoline is stored can cause a fire or explosion.
- This section covers removal and installation of the frame body panels, fuel tank and exhaust system.
- Always replace the exhaust pipe gaskets after removing the exhaust pipe from the engine.
- When installing the exhaust pipe, install all the fasteners loosely. Next, tighten the exhaust pipe joint nuts first, then tighten the mounting fasteners. If you tighten the mounting fasteners first, the exhaust pipe may not seat properly.
- Always inspect the exhaust system for leaks after installation.

### Troubleshooting

#### Excessive Exhaust Noise

- Broken exhaust system
- Exhaust gas leak

#### Poor Performance

- Deformed exhaust system
- Exhaust gas leak
- Clogged muffler

## Seat Removal/Installation


Remove the seat by removing the three mounting bolts.

During seat installation, align the seat hook with the frame hook and holes of the seat with the bosses on the side covers.

Install the three mounting bolts.

### CAUTION

- Be careful not to pinch the wire harness between the seat and frame.



## Fuel Tank Removal/Installation

### ⚠ WARNING

- Gasoline is extremely flammable and is explosive under certain conditions.


Remove the seat (above).

Turn the fuel valve OFF.  
Disconnect the fuel tube.  
Remove the mounting bolt and collar.  
Disconnect the breather tube.

Remove the fuel tank.

Install the fuel tank in the reverse order of removal.  
After installation, turn the fuel valve ON and check the fuel line for leakage.

Install the seat (above).




## Side Cover Removal/Installation

Pull the cover bosses from the grommets.  
Slide the cover boss down from the hole in the seat and remove the side cover.

### NOTE

- Be careful not to damage the boss.

Install the side cover in the reverse order of removal.




## Front Side Cover Removal/Installation

Remove the front side cover mounting screw. Then remove the cover by sliding it forward.


Install the front side cover in the reverse order of removal.

### NOTE

- At installation, align the tab of the front side cover with the groove of fuel tank mount bracket.



# Exhaust System Removal/Installation



**⚠ WARNING**

- Do not service the exhaust system while it is hot.


**NOTE**

- When installing the exhaust pipe/muffler, always tighten the exhaust pipe joint nuts first, then tighten the mounting fasteners, see next page.

Procedure		Q'ty	Remarks
	<b>Removal Order</b>		Installation is in the reverse order of removal.
(1)	Rear exhaust pipe protector	1	Installation (page 2-6)
(2)	Rear cylinder head mount bolt	1	
(3)	Rear cylinder head mount bracket bolt	2	
(4)	Rear cylinder head mount bracket	1	
(5)	Rear exhaust pipe band bolt	1	Loosen the band bolt.
(6)	Front exhaust pipe protector	1	
(7)	Front exhaust pipe band bolt	1	Loosen the band bolt.
(8)	Muffler mounting bolt	1	
(9)	Muffler assembly	1	
(10)	Rear exhaust pipe joint nut	2	
(11)	Rear exhaust pipe	1	
(12)	Exhaust pipe gasket	1	
(13)	Front exhaust pipe joint nut	2	
(14)	Front exhaust pipe	1	
(15)	Exhaust pipe gasket	1	

### Rear Exhaust Pipe Protector Installation

Install the rubber cap to the rear exhaust pipe hook.  
Align the hook of the rear exhaust pipe with groove of the rear exhaust pipe protector.




Adjust the clearance by moving the protector.

Standard: 2–5 mm (0.08–0.19 in)


Tighten the exhaust pipe protector bolt.

Torque: 12 N·m (1.2 kg·m, 9 ft·lb)




### Exhaust Pipe/muffler Mounting Fasteners Tightening

When tighten the exhaust pipe/muffler mounting fasteners, while push the exhaust pipe to inside.



## Rear Fender Removal/Installation



**NOTE**

- Route the wire harness properly (page 1-20).


### Requisite Service

- Seat removal/installation (page 2-2).
- Side covers removal/installation (page 2-3)

Procedure		Q'ty	Remarks
	<b>Removal Order</b>		Installation is in the reverse order of removal.
(1)	Rear turn signal light connector	4	Disconnect the connector.
(2)	Brake/taillight connector	3	Disconnect the connector.
(3)	Rear fender mounting bolt/nut	8/4	
(4)	Grab rail	2	
(5)	Rear fender assembly	1	
(6)	Sub frame	1	



## Upper Fairing Removal/Installation (VF750CD)



### CAUTION


- Do not scratch and damage the windscreen.

Procedure	Q'ty	Remarks
<b>Removal Order</b> (1) Upper fairing mounting bolt (2) Upper fairing	3 1	Installation is in the reverse order of removal.  At installation, align the tab of the upper fairing stay with the hole of the cable guide.

### Windscreen Replacement

Remove the screws, plastic washers and rubber washers.  
Remove the windscreen and upper fairing stays.

Installation is in the reverse order of removal.



---

# 3. Maintenance

Service Information	3-1	Valve Clearance	3-5
Service Access Guide	3-2	Drive Chain	3-8
Maintenance Schedule	3-4	Headlight Aim	3-10
Air Cleaner	3-5		

**3**

## Service Information

- Refer to Common Service Manual for items not included in this manual.
- Refer to Specifications (Section 1) for maintenance data.

## Poor Performance At High Speed

		Possible Cause
1. Check ignition timing	Incorrect	• Faulty ICM • Faulty ignition pulse generator
Correct		
↓		
2. Disconnect fuel tube at carburetor	Fuel Flow Restricted	• Clogged fuel line • Clogged fuel tank breather • Clogged fuel strainer screen
Fuel Flows Freely		
↓		
3. Remove the carburetor and check for clogged jets	Clogged	• Clean
Not clogged		
↓		
4. Check valve timing	Incorrect	• Cam sprocket not installed properly
Correct		
↓		
5. Check valve spring	Weak	• Faulty spring
Not Weakened		

## Poor Handling

	Possible Cause
1. If steering is heavy	• Steering stem adjusting nut too tight • Damaged steering head bearings
2. If either wheel is wobbling	• Excessive wheel bearing play • Bent rim • Improperly installed wheel hub • Swingarm pivot bushing excessively worn • Bent frame
3. If the motorcycle pulls to one side	• Faulty shock absorber • Front and rear wheel not aligned • Bent fork • Bent swingarm • Bent axle

# 22. Index

Air Cleaner .....	3-5	Ignition control Module (ICM) Removal/Installation .....	16-10
Housing Removal/Installation .....	5-3	Ignition Pulse Generator Inspection .....	16-9
Alternator .....	15-9	Removal/Installation .....	16-11
Removal/Installation .....	15-10	Ignition Switch Replacement .....	18-9
Battery Removal/Installation .....	15-5	Ignition System Inspection .....	16-8
Brake Pedal Removal/Installation .....	14-8	Ignition Timing .....	16-12
Bulb Replacement .....	18-5	Liquid Sealant Application .....	11-18
CT Bolt (Technical Feature) .....	20-1	Lubrication & Seal Points .....	1-17
Cable & Harness Routing .....	1-20	Lubrication System Diagram .....	4-2
Camshaft Installation .....	8-8	Mainshaft Disassembly/Assembly .....	11-10
Removal .....	8-2	Maintenance Schedule .....	3-4
Carburetor Combination .....	5-10	Model Identification .....	1-3
Disassembly/Assembly .....	5-8	Oil Pump Disassembly/Assembly .....	4-4
Removal/Installation .....	5-4	Removal/Installation .....	4-3
Separation .....	5-6	Pulse Secondary Air Injection Control Valve (PAIR Control Valve) Removal/Installation (California Type Only) .....	5-18
Synchronization .....	5-14	Pilot Screw Adjustment .....	5-16
Tube Routing (California Type Only) .....	5-13	Piston Disassembly/Assembly .....	11-6
Charging System Inspection .....	15-6	Radiator Disassembly/Assembly .....	6-6
Clutch Installation .....	9-6	Removal/Installation .....	6-5
Removal .....	9-4	Rear Brake Panel Disassembly/Assembly .....	14-7
Combination Meter Disassembly/Assembly .....	18-8	Rear Fender Removal/Installation .....	2-7
Removal/Installation .....	18-7	Rear Wheel Disassembly/Assembly .....	13-4
Connecting Rod Selection .....	11-18	Removal/Installation .....	13-2
Coolant Draining .....	6-3	Regulator/Rectifier .....	15-7
Countershaft Disassembly/Assembly .....	11-12	Right Crankcase Cover Removal/Installation .....	9-2
Crankcase Bolt Location .....	11-18	Seat Removal/Installation .....	2-2
Combination .....	11-14	Service Access Guide .....	3-2
Separation .....	11-2	Service Information (Brake System) .....	14-1
Crankshaft Bearing Replacement .....	11-16	(Charging System/Alternator) .....	15-1
Crankshaft/Connecting Rod Removal/Installation ..	11-4	(Clutch System) .....	9-1
Cylinder Head Disassembly/Assembly .....	8-6	(Cooling System) .....	6-1
Removal/Installation .....	8-4	(Crankshaft/Piston/Transmission) .....	11-1
Drive Chain .....	3-8	(Cylinder Head/Valves) .....	8-1
Drive Sprocket Cover Removal/Installation .....	10-2	(Electric Starter/Starter Clutch) .....	17-1
Emission Control Information Labels (U.S.A. Only) .....	1-30	(Engine Removal/Installation) .....	7-1
Emission Control System .....	1-27	(Frame/Body Panels/Exhaust System) .....	2-1
Engine Removal/Installation .....	7-2	(Front Wheel/Suspension/Steering) .....	12-1
Evaporative Emission Canister (EVAP Canister) Removal/Installation (California Type Only) .....	5-18	(Fuel System) .....	5-1
Exhaust System Removal/Installation .....	2-4	(Gearshift Linkage) .....	10-1
Fork Assembly .....	12-10	(Ignition System) .....	16-1
Disassembly .....	12-8	(Lights/Meters/Switches) .....	18-1
Removal/Installation .....	12-6	(Lubrication System) .....	4-1
Front Brake Caliper Disassembly/Assembly .....	14-4	(Maintenance) .....	3-1
Removal/Installation .....	14-3	(Rear Wheel/Suspension) .....	13-1
Front Brake Pad Replacement .....	14-2	Shock Absorber Disassembly/Assembly .....	13-7
Front Master Cylinder Disassembly/Assembly .....	14-6	Removal/Installation .....	13-6
Removal/Installation .....	14-5	Side Cover Removal/Installation .....	2-3
Front Side Cover Removal/Installation .....	2-3	Side Stand Switch .....	18-9
Front Wheel Disassembly/Assembly .....	12-5	Specifications .....	1-4
Removal/Installation .....	12-4	Starter Clutch Disassembly/Assembly .....	17-12
Fuel Tank Removal/Installation .....	2-2	Removal/Installation .....	17-10
Gearshift Linkage Removal/Installation .....	10-4	Starter Motor Disassembly/Assembly .....	17-8
General Safety .....	1-1	Removal/Installation .....	17-7
Handlebar Removal/Installation .....	12-2	Steering Stem Removal/Installation .....	12-12
Headlight Aim .....	3-10	Swingarm Disassembly/Assembly .....	13-11
Removal/Installation .....	18-6	Removal/Installation .....	13-9
High Altitude Adjustment (U.S.A. Only) .....	5-17	System Flow Pattern .....	6-2
Ignition Coil Inspection .....	16-8		
Removal/Installation .....	16-9		

## Index

---

System Location (Charging System/Alternator) ....	15-2
(Electric Starter/Starter Clutch) .....	17-2
(Ignition System) .....	16-2
(Lights/Meters/Switches) .....	18-2
Thermostat Removal/Installation .....	6-4
Tools .....	1-15
Torque Values .....	1-12
Transmission Removal/Installation .....	11-8
Troubleshooting (Brake System) .....	14-1
(Charging System/Alternator) .....	15-3
(Clutch System) .....	9-1
(Cooling System) .....	6-1
(Crankshaft/Piston/Transmission) .....	11-1
(Cylinder Head/Valves) .....	8-1
(Electric Starter/Starter Clutch) .....	17-3
(Engine Does Not Start Or Is Hard To Start)	21-1
(Engine Lacks Power) .....	21-2
(Frame/Body Panels/Exhaust System) .....	2-1
(Front Wheel/Suspension/Steering) .....	12-1
(Fuel System) .....	5-2
(Gearshift Linkage) .....	10-1
(Ignition System) .....	16-3
(Lights/Meters/Switches) .....	18-3
(Lubrication System) .....	4-1
(Poor Handling) .....	21-4
(Poor Performance At High Speed) .....	21-4
(Poor Performance At Low And Idle Speeds)...	21-3
(Rear Wheel/Suspension) .....	13-1
Upper Fairing Removal/Installation (VF750CD).....	2-8
Valve Clearance .....	3-5
Water Pump Removal/Installation .....	6-7
Wiring Diagram .....	19-1